

3M™ Thinsulate™ Window Film

Cleaning and Care Instructions (for Home Owners)

3M™ Thinsulate™ Window Film has been installed on your windows. It is important that you follow the listed care instruction to maintain the durability of the film. If in doubt please contact your 3M™ Licensed Thinsulate™ Window Film installer for guidance. In the event your windows need cleaning, such maintenance can be carried out as follows using recommended material & cleaning methods:

Material to be used	Cleaning Method
Commercially available window cleaner (eg. Windex) & Nonabrasive paper towel	Light wiping motion
Clean & dry lint free soft cloth (e.g. microfiber cloth (see important note below))	Light wiping motion (WITHOUT water or window cleaner)
Commercially available window cleaner (e.g Windex) with window cleaning squeegee	Side to side. Ensure squeegee is free from dirt, nicks and any other contamination
Isopropyl Alcohol with nonabrasive paper towel	Light wiping motion

Important note:

DO NOT use a damp microfiber cloth.

DO NOT Use knives, scrapers, brushes, abrasives etc. to clean the film

DO NOT rub vigorously

DO NOT rub repeatedly in one area.

DO NOT apply heavy pressure in any cleaning operation.

General care:

- Do not affix tapes, suction cups, stickers, etc. to the film surface. Doing so will reduce the low emissivity properties of the film, and will void your product warranty.
- Removal and replacement of window grids will reduce the low emissivity properties of the window and can damage the film.

